Contrôle S3 – Corrigé
Architecture des ordinateurs

Durée : 1 h 30

Répondre exclusivement sur le document réponse.

Exercice 1 (5 points)

Remplir le tableau présent sur le document réponse. Donnez le nouveau contenu des registres (sauf le **PC**) et/ou de la mémoire modifiés par les instructions. **Vous utiliserez la représentation hexadécimale**. **La mémoire et les registres sont réinitialisés à chaque nouvelle instruction.**

Valeurs initiales :

```
D0 = $FFFF0010   A0 = $00005000   PC = $00006000
D1 = $10000002   A1 = $00005008
D2 = $FFFFFFF0   A2 = $00005010

$005000   54 AF 18 B9 E7 21 48 C0
$005008   C9 10 11 C8 D4 36 1F 88
$005010   13 79 01 80 42 1A 2D 49
```

Exercice 2 (4 points)

Remplissez le tableau présent sur le document réponse. Donnez le résultat des additions ainsi que le contenu des bits **N**, **Z**, **V** et **C** du registre d'état.

Exercice 3 (2 points)

Soit les programmes ci-dessous. Complétez le tableau présent sur le document réponse.

```
move.l  #$76543210,d1
ror.l   #8,d1
ror.b   #4,d1
swap    d1
ror.b   #4,d1
```

```
move.l  #$76543210,d2
ror.b   #4,d2
ror.w   #8,d2
ror.b   #4,d2
ror.w   #8,d2
```

Exercice 4 (3 points)

Répondez aux questions sur le document réponse.

Exercice 5 (6 points)

Soit le programme ci-dessous. Complétez le tableau présent sur le document réponse.

```
Main        move.l  #$158f,d7

next1       moveq.l #1,d1
            tst.b   d7
            bpl     next2
            moveq.l #2,d1

next2       moveq.l #1,d2
            tst.l   d7
            bmi     next3
            moveq.l #2,d2

next3       clr.l   d3
            move.l  #$87654321,d0
loop3       addq.l  #1,d3
            subq.w  #1,d0
            bne     loop3

next4       clr.l   d4
            move.w  #$aa,d0
loop4       addq.l  #1,d4
            dbra    d0,loop4        ; DBRA = DBF

next5       moveq.l #1,d5
            cmp.b   #$42,d7
            bgt     next6
            moveq.l #2,d5

next6       moveq.l #1,d6
            cmp.b   #$42,d7
            bls     quit
            moveq.l #2,d6

quit        illegal
```

EASy68K Quick Reference v1.8 http://www.wowgwep.com/EASy68K.htm

Opcode	Size	Operand	CCR	Effective Address s=source, d=destination, e=either, i=displacement												Operation	Description
	BWL	s,d	XNZVC	Dn	An	(An)	(An)+	-(An)	(i,An)	(i,An,Rn)	abs.W	abs.L	(i,PC)	(i,PC,Rn)	#n		
ABCD	B	Dy,Dx	*U*U*	e	-	-	-	-	-	-	-	-	-	-	-	$Dy_{10} + Dx_{10} + X \rightarrow Dx_{10}$	Add BCD source and eXtend bit to
		-(Ay),-(Ax)		-	-	-	-	e	-	-	-	-	-	-	-	$-(Ay)_{10} + -(Ax)_{10} + X \rightarrow -(Ax)_{10}$	destination, BCD result
ADD [4]	BWL	s,Dn	*****	e	s	s	s	s	s	s	s	s	s	s	s[4]	s + Dn → Dn	Add binary (ADDI or ADDQ is used when
		Dn,d		e	d[4]	d	d	d	d	d	d	d	-	-	-	Dn + d → d	source is #n. Prevent ADDQ with #n.L)
ADDA [4]	WL	s,An	-----	s	e	s	s	s	s	s	s	s	s	s	s	s + An → An	Add address (.W sign-extended to .L)
ADDI [4]	BWL	#n,d	*****	d	-	d	d	d	d	d	d	d	-	-	s	#n + d → d	Add immediate to destination
ADDQ [4]	BWL	#n,d	*****	d	d	d	d	d	d	d	d	d	-	-	s	#n + d → d	Add quick immediate (#n range: 1 to 8)
ADDX	BWL	Dy,Dx	*****	e	-	-	-	-	-	-	-	-	-	-	-	Dy + Dx + X → Dx	Add source and eXtend bit to destination
		-(Ay),-(Ax)		-	-	-	-	e	-	-	-	-	-	-	-	-(Ay) + -(Ax) + X → -(Ax)	
AND [4]	BWL	s,Dn	-**00	e	-	s	s	s	s	s	s	s	s	s	s[4]	s AND Dn → Dn	Logical AND source to destination
		Dn,d		e	-	d	d	d	d	d	d	d	-	-	-	Dn AND d → d	(ANDI is used when source is #n)
ANDI [4]	BWL	#n,d	-**00	d	-	d	d	d	d	d	d	d	-	-	s	#n AND d → d	Logical AND immediate to destination
ANDI [4]	B	#n,CCR	=====	-	-	-	-	-	-	-	-	-	-	-	s	#n AND CCR → CCR	Logical AND immediate to CCR
ANDI [4]	W	#n,SR	=====	-	-	-	-	-	-	-	-	-	-	-	s	#n AND SR → SR	Logical AND immediate to SR (Privileged)
ASL	BWL	Dx,Dy	*****	e	-	-	-	-	-	-	-	-	-	-	-		Arithmetic shift Dy by Dx bits left/right
ASR		#n,Dy		d	-	-	-	-	-	-	-	-	-	-	s		Arithmetic shift Dy #n bits L/R (#n: 1 to 8)
	W	d		-	-	d	d	d	d	d	d	d	-	-	-		Arithmetic shift ds 1 bit left/right (.W only)
Bcc	BW[3]	address[2]	-----	-	-	-	-	-	-	-	-	-	-	-	-	if cc true then	Branch conditionally (cc table on back)
																address → PC	(8 or 16-bit ± offset to address)
BCHG	B L	Dn,d	--*--	e[1]	-	d	d	d	d	d	d	d	-	-	-	NOT(bit number of d) → Z	Set Z with state of specified bit in d then
		#n,d		d[1]	-	d	d	d	d	d	d	d	-	-	s	NOT(bit n of d)→ bit n of d	invert the bit in d
BCLR	B L	Dn,d	--*--	e[1]	-	d	d	d	d	d	d	d	-	-	-	NOT(bit number of d) → Z	Set Z with state of specified bit in d then
		#n,d		d[1]	-	d	d	d	d	d	d	d	-	-	s	0 → bit number of d	clear the bit in d
BRA	BW[3]	address[2]	-----	-	-	-	-	-	-	-	-	-	-	-	-	address → PC	Branch always (8 or 16-bit ± offset to addr)
BSET	B L	Dn,d	--*--	e[1]	-	d	d	d	d	d	d	d	-	-	-	NOT(bit n of d) → Z	Set Z with state of specified bit in d then
		#n,d		d[1]	-	d	d	d	d	d	d	d	-	-	s	1 → bit n of d	set the bit in d
BSR	BW[3]	address[2]	-----	-	-	-	-	-	-	-	-	-	-	-	-	PC → -(SP); address → PC	Branch to subroutine (8 or 16-bit ± offset)
BTST	B L	Dn,d	--*--	e[1]	-	d	d	d	d	d	d	d	d	d	-	NOT(bit Dn of d) → Z	Set Z with state of specified bit in d
		#n,d		d[1]	-	d	d	d	d	d	d	d	d	d	s	NOT(bit #n of d) → Z	Leave the bit in d unchanged
CHK	W	s,Dn	-*UUU	e	-	s	s	s	s	s	s	s	s	s	s	if Dn<0 or Dn>s then TRAP	Compare Dn with 0 and upper bound [s]
CLR	BWL	d	-0100	d	-	d	d	d	d	d	d	d	-	-	-	0 → d	Clear destination to zero
CMP [4]	BWL	s,Dn	-****	e	s[4]	s	s	s	s	s	s	s	s	s	s[4]	set CCR with Dn – s	Compare Dn to source
CMPA [4]	WL	s,An	-****	s	e	s	s	s	s	s	s	s	s	s	s	set CCR with An – s	Compare An to source
CMPI [4]	BWL	#n,d	-****	d	-	d	d	d	d	d	d	d	-	-	s	set CCR with d - #n	Compare destination to #n
CMPM [4]	BWL	(Ay)+,(Ax)+	-****	-	-	-	e	-	-	-	-	-	-	-	-	set CCR with (Ax) - (Ay)	Compare (Ax) to (Ay); Increment Ax and Ay
DBcc	W	Dn,addres[2]	-----	-	-	-	-	-	-	-	-	-	-	-	-	if cc false then { Dn-1 → Dn	Test condition, decrement and branch
																if Dn <> -1 then addr →PC }	(16-bit ± offset to address)
DIVS	W	s,Dn	-***0	e	-	s	s	s	s	s	s	s	s	s	s	±32bit Dn / ±16bit s → ±Dn	Dn= [16-bit remainder, 16-bit quotient]
DIVU	W	s,Dn	-***0	e	-	s	s	s	s	s	s	s	s	s	s	32bit Dn / 16bit s → Dn	Dn= [16-bit remainder, 16-bit quotient]
EOR [4]	BWL	Dn,d	-**00	e	-	d	d	d	d	d	d	d	-	-	s[4]	Dn XOR d → d	Logical exclusive OR Dn to destination
EORI [4]	BWL	#n,d	-**00	d	-	d	d	d	d	d	d	d	-	-	s	#n XOR d → d	Logical exclusive OR #n to destination
EORI [4]	B	#n,CCR	=====	-	-	-	-	-	-	-	-	-	-	-	s	#n XOR CCR → CCR	Logical exclusive OR #n to CCR
EORI [4]	W	#n,SR	=====	-	-	-	-	-	-	-	-	-	-	-	s	#n XOR SR → SR	Logical exclusive OR #n to SR (Privileged)
EXG	L	Rx,Ry	-----	e	e	-	-	-	-	-	-	-	-	-	-	register ← → register	Exchange registers (32-bit only)
EXT	WL	Dn	-**00	d	-	-	-	-	-	-	-	-	-	-	-	Dn.B → Dn.W | Dn.W → Dn.L	Sign extend (change .B to .W or .W to .L)
ILLEGAL			-----	-	-	-	-	-	-	-	-	-	-	-	-	PC→-(SSP); SR→-(SSP)	Generate Illegal Instruction exception
JMP		d	-----	-	-	d	-	-	d	d	d	d	d	d	-	↑d → PC	Jump to effective address of destination
JSR		d	-----	-	-	d	-	-	d	d	d	d	d	d	-	PC → -(SP); ↑d → PC	push PC, jump to subroutine at address d
LEA	L	s,An	-----	-	e	s	-	-	s	s	s	s	s	s	-	↑s → An	Load effective address of s to An
LINK		An,#n	-----	-	-	-	-	-	-	-	-	-	-	-	-	An → -(SP); SP → An;	Create local workspace on stack
																SP + #n → SP	(negative n to allocate space)
LSL	BWL	Dx,Dy	***0*	e	-	-	-	-	-	-	-	-	-	-	-		Logical shift Dy, Dx bits left/right
LSR		#n,Dy		d	-	-	-	-	-	-	-	-	-	-	s		Logical shift Dy, #n bits L/R (#n: 1 to 8)
	W	d		-	-	d	d	d	d	d	d	d	-	-	-		Logical shift d 1 bit left/right (.W only)
MOVE [4]	BWL	s,d	-**00	e	s[4]	e	e	e	e	e	e	e	s	s	s[4]	s → d	Move data from source to destination
MOVE	W	s,CCR	=====	s	-	s	s	s	s	s	s	s	s	s	s	s → CCR	Move source to Condition Code Register
MOVE	W	s,SR	=====	s	-	s	s	s	s	s	s	s	s	s	s	s → SR	Move source to Status Register (Privileged)
MOVE	W	SR,d	-----	d	-	d	d	d	d	d	d	d	-	-	-	SR → d	Move Status Register to destination
MOVE	L	USP,An	-----	-	d	-	-	-	-	-	-	-	-	-	-	USP → An	Move User Stack Pointer to An (Privileged)
		An,USP		-	s	-	-	-	-	-	-	-	-	-	-	An → USP	Move An to User Stack Pointer (Privileged)
	BWL	s,d	XNZVC	Dn	An	(An)	(An)+	-(An)	(i,An)	(i,An,Rn)	abs.W	abs.L	(i,PC)	(i,PC,Rn)	#n		

Opcode	Size	Operand	CCR	Effective Address s=source, d=destination, e=either, i=displacement											Operation	Description
	BWL	s,d	XNZVC	Dn	An	(An)	(An)+	-(An)	(i,An)	(i,An,Rn)	abs.W	abs.L	(i,PC)	(i,PC,Rn)	#n	
MOVEA[4]	WL	s,An	-----	s	e	s	s	s	s	s	s	s	s	s	s	s → An	Move source to An (MOVE s,An use MOVEA)
MOVEM[4]	WL	Rn-Rn,d	-----	-	-	d	-	d	d	d	d	d	-	-	-	Registers → d	Move specified registers to/from memory
		s,Rn-Rn		-	-	s	s	-	s	s	s	s	s	s	-	s → Registers	(.W source is sign-extended to .L for Rn)
MOVEP	WL	Dn,(i,An)	-----	s	-	-	-	-	d	-	-	-	-	-	-	Dn → (i,An)...(i+2,An)...(i+4,A.	Move Dn to/from alternate memory bytes
		(i,An),Dn		d	-	-	-	-	s	-	-	-	-	-	-	(i,An) → Dn...(i+2,An)...(i+4,A.	(Access only even or odd addresses)
MOVEQ[4]	L	#n,Dn	-**00	d	-	-	-	-	-	-	-	-	-	-	s	#n → Dn	Move sign extended 8-bit #n to Dn
MULS	W	s,Dn	-**00	e	-	s	s	s	s	s	s	s	s	s	s	±16bit s * ±16bit Dn → ±Dn	Multiply signed 16-bit; result: signed 32-bit
MULU	W	s,Dn	-**00	e	-	s	s	s	s	s	s	s	s	s	s	16bit s * 16bit Dn → Dn	Multiply unsig'd 16-bit; result: unsig'd 32-bit
NBCD	B	d	*U*U*	d	-	d	d	d	d	d	d	d	-	-	-	$0 - d_{10} - X \rightarrow d$	Negate BCD with eXtend, BCD result
NEG	BWL	d	*****	d	-	d	d	d	d	d	d	d	-	-	-	0 - d → d	Negate destination (2's complement)
NEGX	BWL	d	*****	d	-	d	d	d	d	d	d	d	-	-	-	0 - d - X → d	Negate destination with eXtend
NOP			-----	-	-	-	-	-	-	-	-	-	-	-	-	None	No operation occurs
NOT	BWL	d	-**00	d	-	d	d	d	d	d	d	d	-	-	-	NOT(d) → d	Logical NOT destination (1's complement)
OR[4]	BWL	s,Dn	-**00	e	-	s	s	s	s	s	s	s	s	s	s^4	s OR Dn → Dn	Logical OR
		Dn,d		e	-	d	d	d	d	d	d	d	-	-	-	Dn OR d → d	(ORI is used when source is #n)
ORI[4]	BWL	#n,d	-**00	d	-	d	d	d	d	d	d	d	-	-	s	#n OR d → d	Logical OR #n to destination
ORI[4]	B	#n,CCR	=====	-	-	-	-	-	-	-	-	-	-	-	s	#n OR CCR → CCR	Logical OR #n to CCR
ORI[4]	W	#n,SR	=====	-	-	-	-	-	-	-	-	-	-	-	s	#n OR SR → SR	Logical OR #n to SR (Privileged)
PEA	L	s	-----	-	-	s	-	-	s	s	s	s	s	s	-	↑s → -(SP)	Push effective address of s onto stack
RESET			-----	-	-	-	-	-	-	-	-	-	-	-	-	Assert RESET Line	Issue a hardware RESET (Privileged)
ROL	BWL	Dx,Dy	-**0*	e	-	-	-	-	-	-	-	-	-	-	-		Rotate Dy, Dx bits left/right (without X)
ROR		#n,Dy		d	-	-	-	-	-	-	-	-	-	-	s		Rotate Dy, #n bits left/right (#n: 1 to 8)
	W	d		-	-	d	d	d	d	d	d	d	-	-	-		Rotate d 1-bit left/right (.W only)
ROXL	BWL	Dx,Dy	***0*	e	-	-	-	-	-	-	-	-	-	-	-		Rotate Dy, Dx bits L/R, X used then updated
ROXR		#n,Dy		d	-	-	-	-	-	-	-	-	-	-	s		Rotate Dy, #n bits left/right (#n: 1 to 8)
	W	d		-	-	d	d	d	d	d	d	d	-	-	-		Rotate destination 1-bit left/right (.W only)
RTE			=====	-	-	-	-	-	-	-	-	-	-	-	-	(SP)+ → SR; (SP)+ → PC	Return from exception (Privileged)
RTR			=====	-	-	-	-	-	-	-	-	-	-	-	-	(SP)+ → CCR, (SP)+ → PC	Return from subroutine and restore CCR
RTS			-----	-	-	-	-	-	-	-	-	-	-	-	-	(SP)+ → PC	Return from subroutine
SBCD	B	Dy,Dx	*U*U*	e	-	-	-	-	-	-	-	-	-	-	-	$Dx_{10} - Dy_{10} - X \rightarrow Dx_{10}$	Subtract BCD source and eXtend bit from
		-(Ay),-(Ax)		-	-	-	-	e	-	-	-	-	-	-	-	$-(Ax)_{10} - -(Ay)_{10} - X \rightarrow -(Ax)_{10}$	destination, BCD result
Scc	B	d	-----	d	-	d	d	d	d	d	d	d	-	-	-	If cc is true then 1's → d else 0's → d	If cc true then d.B = 11111111 else d.B = 00000000
STOP		#n	=====	-	-	-	-	-	-	-	-	-	-	-	s	#n → SR; STOP	Move #n to SR, stop processor (Privileged)
SUB[4]	BWL	s,Dn	*****	e	s	s	s	s	s	s	s	s	s	s	s^4	Dn - s → Dn	Subtract binary (SUBI or SUBQ used when
		Dn,d		e	d^4	d	d	d	d	d	d	d	-	-	-	d - Dn → d	source is #n. Prevent SUBQ with #n.L)
SUBA[4]	WL	s,An	-----	s	e	s	s	s	s	s	s	s	s	s	s	An - s → An	Subtract address (.W sign-extended to .L)
SUBI[4]	BWL	#n,d	*****	d	-	d	d	d	d	d	d	d	-	-	s	d - #n → d	Subtract immediate from destination
SUBQ[4]	BWL	#n,d	*****	d	d	d	d	d	d	d	d	d	-	-	s	d - #n → d	Subtract quick immediate (#n range: 1 to 8)
SUBX	BWL	Dy,Dx	*****	e	-	-	-	-	-	-	-	-	-	-	-	Dx - Dy - X → Dx	Subtract source and eXtend bit from
		-(Ay),-(Ax)		-	-	-	-	e	-	-	-	-	-	-	-	-(Ax) - -(Ay) – X → -(Ax)	destination
SWAP	W	Dn	-**00	d	-	-	-	-	-	-	-	-	-	-	-	bits[31:16]←→bits[15:0]	Exchange the 16-bit halves of Dn
TAS	B	d	-**00	d	-	d	d	d	d	d	d	d	-	-	-	test d→CCR; 1 →bit7 of d	N and Z set to reflect d, bit7 of d set to 1
TRAP		#n	-----	-	-	-	-	-	-	-	-	-	-	-	s	PC→-(SSP);SR→-(SSP); (vector table entry) → PC	Push PC and SR, PC set by vector table #n (#n range: 0 to 15)
TRAPV			-----	-	-	-	-	-	-	-	-	-	-	-	-	If V then TRAP #7	If overflow, execute an Overflow TRAP
TST	BWL	d	-**00	d	-	d	d	d	d	d	d	d	-	-	-	test d → CCR	N and Z set to reflect destination
UNLK		An	-----	-	d	-	-	-	-	-	-	-	-	-	-	An → SP; (SP)+ → An	Remove local workspace from stack
	BWL	s,d	XNZVC	Dn	An	(An)	(An)+	-(An)	(i,An)	(i,An,Rn)	abs.W	abs.L	(i,PC)	(i,PC,Rn)	#n		

Condition Tests (+ OR, ! NOT, ⊕ XOR; ᵘ Unsigned, ᵃ Alternate cc)					
cc	**Condition**	**Test**	**cc**	**Condition**	**Test**
T	true	1	VC	overflow clear	!V
F	false	0	VS	overflow set	V
HIᵘ	higher than	!(C + Z)	PL	plus	!N
LSᵘ	lower or same	C + Z	MI	minus	N
HSᵘ, CCᵃ	higher or same	!C	GE	greater or equal	!(N ⊕ V)
LOᵘ, CSᵃ	lower than	C	LT	less than	(N ⊕ V)
NE	not equal	!Z	GT	greater than	![(N ⊕ V) + Z]
EQ	equal	Z	LE	less or equal	(N ⊕ V) + Z

Revised by Peter Csaszar, Lawrence Tech University – 2004-2006

An Address register (16/32-bit, n=0-7)
Dn Data register (8/16/32-bit, n=0-7)
Rn any data or address register
s Source, **d** Destination
e Either source or destination
#n Immediate data, **i** Displacement
BCD Binary Coded Decimal
↑ Effective address

1 Long only; all others are byte only
2 Assembler calculates offset
3 Branch sizes: **.B** or **.S** -128 to +127 bytes, **.W** or **.L** -32768 to +32767 bytes
4 Assembler automatically uses A, I, Q or M form if possible. Use #n.L to prevent Quick optimization

SSP Supervisor Stack Pointer (32-bit)
USP User Stack Pointer (32-bit)
SP Active Stack Pointer (same as A7)
PC Program Counter (24-bit)

SR Status Register (16-bit)
CCR Condition Code Register (lower 8-bits of SR)
N negative, **Z** zero, **V** overflow, **C** carry, **X** extend
***** set according to operation's result, ≡ set directly
- not affected, **0** cleared, **1** set, **U** undefined

Nom : ..... Prénom : ..... Classe : .....

DOCUMENT RÉPONSE À RENDRE

Exercice 1

Instruction	Mémoire	Registre
Exemple	`$005000 54 AF [00 40] E7 21 48 C0`	A0 = `$00005004` A1 = `$0000500C`
Exemple	`$005008 C9 10 11 C8 D4 36 [FF] 88`	Aucun changement
`MOVE.W #$500A,-(A1)`	`$005000 54 AF 18 B9 E7 21 [50 0A]`	A1 = `$00005006`
`MOVE.W $500A,-2(A1)`	`$005000 54 AF 18 B9 E7 21 [11 C8]`	Aucun changement
`MOVE.L $500A,-(A1)`	`$005000 54 AF 18 B9 [11 C8 D4 36]`	A1 = `$00005004`
`MOVE.B 5(A1),3(A2,D2.L)`	`$005000 54 AF 18 [36] E7 21 48 C0`	Aucun changement
`MOVE.L -4(A1),-16(A2,D0.W)`	`$005010 [E7 21 48 C0] 42 1A 2D 49`	Aucun changement

Exercice 2

Opération	Taille (bits)	Résultat (hexadécimal)	N	Z	V	C
`$5A + $35`	8	`$8F`	1	0	1	0
`$5A + $35`	16	`$008F`	0	0	0	0
`$7F8C + $FFFF`	16	`$7F8B`	0	0	0	1
`$FFFFFFF0 + $00000010`	32	`$00000000`	0	1	0	1

Exercice 3

Valeurs des registres après exécution du programme. **Utilisez la représentation hexadécimale sur 32 bits.**	
D1 = $54231067	**D2** = $76542301

Exercice 4

Question	**Réponse**
Combien de registres de donnée possède le 68000 ?	**8** (D0, D1, D2, D3, D4, D5, D6, D7)
Combien de registres d'adresse possède le 68000 ?	**8** (A0, A1, A2, A3, A4, A5, A6, A7)
Combien de compteurs programme possède le 68000 ?	**1** (PC)
Combien de pointeurs de pile possède le 68000 ?	**2** (SSP, USP)
Combien de registres d'état possède le 68000 ?	**1** (SR)
Combien de modes de fonctionnement possède le 68000 ?	**2** (superviseur et utilisateur)

Exercice 5

Valeurs des registres après exécution du programme. **Utilisez la représentation hexadécimale sur 32 bits.**		
D1 = $00000002	**D3** = $00004321	**D5** = $00000002
D2 = $00000002	**D4** = $000000AB	**D6** = $00000002