

Contrôle S3 – Corrigé

Architecture des ordinateurs

Durée : 1 h 30

Répondre exclusivement sur le document réponse.

Exercice 1 (5 points)

Remplir le tableau présent sur le [document réponse](#). Donnez le nouveau contenu des registres (sauf le PC) et/ou de la mémoire modifiés par les instructions. **Vous utiliserez la représentation hexadécimale. La mémoire et les registres sont réinitialisés à chaque nouvelle instruction.**

Valeurs initiales : D0 = \$FFFF0005 A0 = \$00005000 PC = \$00006000
 D1 = \$00000008 A1 = \$00005008
 D2 = \$0000FFFA A2 = \$00005010

\$005000	54	AF	18	B9	E7	21	48	C0
\$005008	C9	10	11	C8	D4	36	1F	88
\$005010	13	79	01	80	42	1A	2D	49

Exercice 2 (4 points)

Remplissez le tableau présent sur le [document réponse](#). Donnez le résultat des additions ainsi que le contenu des bits N, Z, V et C du registre d'état.

Exercice 3 (3 points)

Réalisez le sous-programme **AlphaCount** qui renvoie le nombre de caractères alphanumériques dans une chaîne de caractères. Une chaîne de caractères se termine par un caractère nul (la valeur zéro). À l'exception des registres de sortie, aucun registre de donnée ou d'adresse ne devra être modifié en sortie de ce sous-programme.

Entrée : **A0.L** pointe sur le premier caractère d'une chaîne de caractères.

Sortie : **D0.L** renvoie le nombre de caractères alphanumériques de la chaîne.

Indications :

- Un caractère alphanumérique est une lettre (minuscule ou majuscule) ou un chiffre (de 0 à 9).
- On considère que les trois sous-programmes ci-dessous sont déjà écrits et que vous pouvez les appeler (ils ne modifient que **D0**) :
 - **LowerCount** renvoie dans **D0** le nombre de minuscules dans une chaîne pointée par **A0**.
 - **UpperCount** renvoie dans **D0** le nombre de majuscules dans une chaîne pointée par **A0**.
 - **DigitCount** renvoie dans **D0** le nombre de chiffres dans une chaîne pointée par **A0**.

Attention ! le sous-programme AlphaCount est limité à 10 lignes d'instructions.






Exercice 4 (2 points)

Répondez aux questions sur le [document réponse](#).





Exercice 5 (6 points)

Soit le programme ci-dessous. Complétez le tableau présent sur le [document réponse](#).

Main	<code>move.l #520037f0,d7</code>
next1	<code>moveq.l #1,d1</code> <code>tst.w d7</code> <code>beq next2</code> <code>moveq.l #2,d1</code>
next2	<code>moveq.l #1,d2</code> <code>cmpi.l #ffffff,d7</code> <code>blo next3</code> <code>moveq.l #2,d2</code>
next3	<code>clr.l d3</code> <code>move.l #66666666,d0</code>
loop3	<code>addq.l #1,d3</code> <code>subq.b #2,d0</code> <code>bne loop3</code>
next4	<code>clr.l d4</code> <code>move.l #66666666,d0</code>
loop4	<code>addq.l #1,d4</code> <code>dbra d0,loop4 ; DBRA = DBF</code>
next5	<code>move.l d7,d5</code> <code>move.w #ffff,d5</code> <code>swap d5</code> <code>tst.b d5</code> <code>beq next6</code> <code>swap d5</code>
next6	<code>move.l d7,d6</code> <code>ror.b #4,d6</code> <code>ror.w #4,d6</code> <code>swap d6</code> <code>rol.l #8,d6</code> <code>rol.l #4,d6</code> <code>ror.w #8,d6</code>
quit	<code>illegal</code>

Opcode	Size	Operand	CCR	Effective Address s=source, d=destination, e=either, i=displacement											Operation	Description		
	BWL	s,d	XNZVC	Dn	An	(An)	(An)+	-(An)	(i.An)	(i.An,Rn)	abs.W	abs.L	(i.PC)	(i.PC,Rn)	#n			
ABCD	B	Dy,Dx -(Ay),-(Ax)	*U*U*	e	-	-	-	-	-	-	-	-	-	-	-	-	$Dy_{10} + Dx_{10} + X \rightarrow Dx_{10}$ $-(Ay)_{10} + -(Ax)_{10} + X \rightarrow -(Ax)_{10}$	Add BCD source and eXtend bit to destination, BCD result
ADD ⁴	BWL	s,Dn Dn,d	*****	e	s ⁴	s	s	s	s	s	s	s	s	s	s	s	$s + Dn \rightarrow Dn$ $Dn + d \rightarrow d$	Add binary (ADDI or ADDQ is used when source is #n. Prevent ADDQ with #n.L)
ADDA ⁴	WL	s,An	-----	s	e	s	s	s	s	s	s	s	s	s	s	s	$s + An \rightarrow An$	Add address (.W sign-extended to .L)
ADDI ⁴	BWL	#n,d	*****	d	-	d	d	d	d	d	d	d	-	-	-	s	$\#n + d \rightarrow d$	Add immediate to destination
ADDQ ⁴	BWL	#n,d	*****	d	d	d	d	d	d	d	d	d	-	-	-	s	$\#n + d \rightarrow d$	Add quick immediate (#n range: 1 to 8)
ADDX	BWL	Dy,Dx -(Ay),-(Ax)	*****	e	-	-	-	-	-	-	-	-	-	-	-	-	$Dy + Dx + X \rightarrow Dx$ $-(Ay) + -(Ax) + X \rightarrow -(Ax)$	Add source and eXtend bit to destination
AND ⁴	BWL	s,Dn Dn,d	-**00	e	-	s	s	s	s	s	s	s	s	s	s	s	$s \text{ AND } Dn \rightarrow Dn$ $Dn \text{ AND } d \rightarrow d$	Logical AND source to destination (ANDI is used when source is #n)
ANDI ⁴	BWL	#n,d	-**00	d	-	d	d	d	d	d	d	d	-	-	-	s	$\#n \text{ AND } d \rightarrow d$	Logical AND immediate to destination
ANDI ⁴	B	#n,CCR	=====	-	-	-	-	-	-	-	-	-	-	-	-	s	$\#n \text{ AND } CCR \rightarrow CCR$	Logical AND immediate to CCR
ANDI ⁴	W	#n,SR	=====	-	-	-	-	-	-	-	-	-	-	-	-	s	$\#n \text{ AND } SR \rightarrow SR$	Logical AND immediate to SR (Privileged)
ASL	BWL	Dx,Dy	*****	e	-	-	-	-	-	-	-	-	-	-	-	-		Arithmetic shift Dy by Dx bits left/right
ASR	BWL	#n,Dy	*****	d	-	-	-	-	-	-	-	-	-	-	-	s	$\#n \text{ bits L/R}$	Arithmetic shift Dy #n bits L/R (#n: 1 to 8)
	W	d	*****	-	-	d	d	d	d	d	d	d	-	-	-	-		Arithmetic shift ds 1 bit left/right (.W only)
Bcc	BW ³	address ²	-----	-	-	-	-	-	-	-	-	-	-	-	-	-	if cc true then address → PC	Branch conditionally (cc table on back) (8 or 16-bit ± offset to address)
BCHG	B L	Dn,d #n,d	---*---	e ^l	-	d	d	d	d	d	d	d	-	-	-	-	$\text{NOT}(\text{bit number of } d) \rightarrow Z$ $\text{NOT}(\text{bit } n \text{ of } d) \rightarrow \text{bit } n \text{ of } d$	Set Z with state of specified bit in d then invert the bit in d
BCLR	B L	Dn,d #n,d	---*---	e ^l	-	d	d	d	d	d	d	d	-	-	-	-	$\text{NOT}(\text{bit number of } d) \rightarrow Z$ $0 \rightarrow \text{bit number of } d$	Set Z with state of specified bit in d then clear the bit in d
BRA	BW ³	address ²	-----	-	-	-	-	-	-	-	-	-	-	-	-	-	address → PC	Branch always (8 or 16-bit ± offset to addr)
BSET	B L	Dn,d #n,d	---*---	e ^l	-	d	d	d	d	d	d	d	-	-	-	-	$\text{NOT}(\text{bit } n \text{ of } d) \rightarrow Z$ $1 \rightarrow \text{bit } n \text{ of } d$	Set Z with state of specified bit in d then set the bit in d
BSR	BW ³	address ²	-----	-	-	-	-	-	-	-	-	-	-	-	-	-	PC → -(SP); address → PC	Branch to subroutine (8 or 16-bit ± offset)
BTST	B L	Dn,d #n,d	---*---	e ^l	-	d	d	d	d	d	d	d	d	d	d	d	$\text{NOT}(\text{bit } Dn \text{ of } d) \rightarrow Z$ $\text{NOT}(\text{bit } \#n \text{ of } d) \rightarrow Z$	Set Z with state of specified bit in d Leave the bit in d unchanged
CHK	W	s,Dn	-*UUU	e	-	s	s	s	s	s	s	s	s	s	s	s	if $Dn < 0$ or $Dn > s$ then TRAP	Compare Dn with 0 and upper bound [s]
CLR	BWL	d	-0100	d	-	d	d	d	d	d	d	d	-	-	-	-	$0 \rightarrow d$	Clear destination to zero
CMP ⁴	BWL	s,Dn	-****	e	s ⁴	s	s	s	s	s	s	s	s	s	s	s	set CCR with $Dn - s$	Compare Dn to source
CMPA ⁴	WL	s,An	-****	s	e	s	s	s	s	s	s	s	s	s	s	s	set CCR with $An - s$	Compare An to source
CMPI ⁴	BWL	#n,d	-****	d	-	d	d	d	d	d	d	d	-	-	-	s	set CCR with $d - \#n$	Compare destination to #n
CMPM ⁴	BWL	(Ay)+,(Ax)+	-****	-	-	-	e	-	-	-	-	-	-	-	-	-	set CCR with $(Ax) - (Ay)$	Compare (Ax) to (Ay); Increment Ax and Ay
DBcc	W	Dn,address ²	-----	-	-	-	-	-	-	-	-	-	-	-	-	-	if cc false then { $Dn - 1 \rightarrow Dn$ if $Dn < -1$ then addr → PC }	Test condition, decrement and branch (16-bit ± offset to address)
DIVS	W	s,Dn	-***0	e	-	s	s	s	s	s	s	s	s	s	s	s	$\pm 32\text{bit } Dn / \pm 16\text{bit } s \rightarrow \pm Dn$	$Dn = [16\text{-bit remainder}, 16\text{-bit quotient}]$
DIVU	W	s,Dn	-***0	e	-	s	s	s	s	s	s	s	s	s	s	s	$32\text{bit } Dn / 16\text{bit } s \rightarrow Dn$	$Dn = [16\text{-bit remainder}, 16\text{-bit quotient}]$
EOR ⁴	BWL	Dn,d	-**00	e	-	d	d	d	d	d	d	d	-	-	-	s ⁴	$Dn \text{ XOR } d \rightarrow d$	Logical exclusive OR Dn to destination
EORI ⁴	BWL	#n,d	-**00	d	-	d	d	d	d	d	d	d	-	-	-	s	$\#n \text{ XOR } d \rightarrow d$	Logical exclusive OR #n to destination
EORI ⁴	B	#n,CCR	=====	-	-	-	-	-	-	-	-	-	-	-	-	s	$\#n \text{ XOR } CCR \rightarrow CCR$	Logical exclusive OR #n to CCR
EORI ⁴	W	#n,SR	=====	-	-	-	-	-	-	-	-	-	-	-	-	s	$\#n \text{ XOR } SR \rightarrow SR$	Logical exclusive OR #n to SR (Privileged)
EXG	L	Rx,Ry	-----	e	e	-	-	-	-	-	-	-	-	-	-	-	register ↔ register	Exchange registers (32-bit only)
EXT	WL	Dn	-**00	d	-	-	-	-	-	-	-	-	-	-	-	-	$Dn.B \rightarrow Dn.W \mid Dn.W \rightarrow Dn.L$	Sign extend (change .B to .W or .W to .L)
ILLEGAL			-----	-	-	-	-	-	-	-	-	-	-	-	-	-	PC → -(SSP); SR → -(SSP)	Generate Illegal Instruction exception
JMP		d	-----	-	-	d	-	-	d	d	d	d	d	d	d	d	$\uparrow d \rightarrow PC$	Jump to effective address of destination
JSR		d	-----	-	-	d	-	-	d	d	d	d	d	d	d	d	PC → -(SP); $\uparrow d \rightarrow PC$	push PC, jump to subroutine at address d
LEA	L	s,An	-----	-	e	s	-	-	s	s	s	s	s	s	s	-	$\uparrow s \rightarrow An$	Load effective address of s to An
LINK		An,#n	-----	-	-	-	-	-	-	-	-	-	-	-	-	-	$An \rightarrow -(SP); SP \rightarrow An;$ $SP + \#n \rightarrow SP$	Create local workspace on stack (negative n to allocate space)
LSL	BWL	Dx,Dy	***0*	e	-	-	-	-	-	-	-	-	-	-	-	-		Logical shift Dy, Dx bits left/right
LSR	BWL	#n,Dy	***0*	d	-	-	-	-	-	-	-	-	-	-	-	-		Logical shift Dy, #n bits L/R (#n: 1 to 8)
	W	d	***0*	-	-	d	d	d	d	d	d	d	-	-	-	-		Logical shift d 1 bit left/right (.W only)
MOVE ⁴	BWL	s,d	-**00	e	s ⁴	e	e	e	e	e	e	e	s	s	s	s	$s \rightarrow d$	Move data from source to destination
MOVE	W	s,CCR	=====	s	-	s	s	s	s	s	s	s	s	s	s	s	$s \rightarrow CCR$	Move source to Condition Code Register
MOVE	W	s,SR	=====	s	-	s	s	s	s	s	s	s	s	s	s	s	$s \rightarrow SR$	Move source to Status Register (Privileged)
MOVE	W	SR,d	-----	d	-	d	d	d	d	d	d	d	-	-	-	-	$SR \rightarrow d$	Move Status Register to destination
MOVE	L	USP,An	-----	-	d	-	-	-	-	-	-	-	-	-	-	-	$USP \rightarrow An$	Move User Stack Pointer to An (Privileged)
		An,USP	-----	-	s	-	-	-	-	-	-	-	-	-	-	-	$An \rightarrow USP$	Move An to User Stack Pointer (Privileged)
	BWL	s,d	XNZVC	Dn	An	(An)	(An)+	-(An)	(i.An)	(i.An,Rn)	abs.W	abs.L	(i.PC)	(i.PC,Rn)	#n			

Architecture des ordinateurs – EPITA – S3 – 2023/2024

Opcode	Size	Operand	CCR	Effective Address s=source, d=destination, e=either, i=displacement											Operation	Description		
	BWL	s,d	XNZVC	Dn	An	(An)	(An)+	-(An)	(i,An)	(i,An,Rn)	abs.W	abs.L	(i,PC)	(i,PC,Rn)	#n			
MOVEA ⁴	WL	s,An	-----	s	e	s	s	s	s	s	s	s	s	s	s	s	s → An	Move source to An (MOVE s,An use MOVEA)
MOVEM ⁴	WL	Rn-Rn,d s,Rn-Rn	-----	-	-	d	-	d	d	d	d	d	-	-	-	-	Registers → d s → Registers	Move specified registers to/from memory (W source is sign-extended to .L for Rn)
MOVEP	WL	Dn,(i,An) (i,An),Dn	-----	s	-	-	-	-	d	-	-	-	-	-	-	-	Dn → (i,An)...(i+2,An)...(i+4,A, (i,An) → Dn...(i+2,An)...(i+4,A,	Move Dn to/from alternate memory bytes (Access only even or odd addresses)
MOVEQ ⁴	L	#n,Dn	---*00	d	-	-	-	-	-	-	-	-	-	-	-	s	#n → Dn	Move sign extended 8-bit #n to Dn
MULS	W	s,Dn	---*00	e	-	s	s	s	s	s	s	s	s	s	s	s	±16bit s * ±16bit Dn → ±Dn	Multiply signed 16-bit; result: signed 32-bit
MULU	W	s,Dn	---*00	e	-	s	s	s	s	s	s	s	s	s	s	s	16bit s * 16bit Dn → Dn	Multiply unsig'd 16-bit; result: unsig'd 32-bit
NBCD	B	d	*U*U*	d	-	d	d	d	d	d	d	d	-	-	-	-	D - d ₁₀ - X → d	Negate BCD with eXtend, BCD result
NEG	BWL	d	*****	d	-	d	d	d	d	d	d	d	-	-	-	-	D - d → d	Negate destination (2's complement)
NEGX	BWL	d	*****	d	-	d	d	d	d	d	d	d	-	-	-	-	D - d - X → d	Negate destination with eXtend
NDP			-----	-	-	-	-	-	-	-	-	-	-	-	-	-	None	No operation occurs
NOT	BWL	d	---*00	d	-	d	d	d	d	d	d	d	-	-	-	-	NOT(d) → d	Logical NOT destination (1's complement)
OR ⁴	BWL	s,Dn Dn,d	---*00	e	-	s	s	s	s	s	s	s	s	s	s	s ⁴	s OR Dn → Dn Dn OR d → d	Logical OR (ORI is used when source is #n)
ORI ⁴	BWL	#n,d	---*00	d	-	d	d	d	d	d	d	d	-	-	-	s	#n OR d → d	Logical OR #n to destination
ORI ⁴	B	#n,CCR	=====	-	-	-	-	-	-	-	-	-	-	-	-	s	#n OR CCR → CCR	Logical OR #n to CCR
ORI ⁴	W	#n,SR	=====	-	-	-	-	-	-	-	-	-	-	-	-	s	#n OR SR → SR	Logical OR #n to SR (Privileged)
PEA	L	s	-----	-	-	s	-	-	s	s	s	s	s	s	s	s	↑s → -(SP)	Push effective address of s onto stack
RESET			-----	-	-	-	-	-	-	-	-	-	-	-	-	-	Assert RESET Line	Issue a hardware RESET (Privileged)
ROL	BWL	Dx,Dy #n,Dy	---*0*	e	-	-	-	-	-	-	-	-	-	-	-	-		Rotate Dy, Dx bits left/right (without X)
ROR	W	d	---*0*	d	-	-	-	-	-	-	-	-	-	-	-	-		Rotate Dy, #n bits left/right (#n: 1 to 8)
RDXL	BWL	Dx,Dy #n,Dy	---*0*	e	-	-	-	-	-	-	-	-	-	-	-	-		Rotate Dy, Dx bits L/R, X used then updated
ROXR	W	d	---*0*	d	-	-	-	-	-	-	-	-	-	-	-	-		Rotate Dy, #n bits left/right (#n: 1 to 8)
RTE			=====	-	-	-	-	-	-	-	-	-	-	-	-	-	(SP)+ → SR; (SP)+ → PC	Return from exception (Privileged)
RTR			=====	-	-	-	-	-	-	-	-	-	-	-	-	-	(SP)+ → CCR; (SP)+ → PC	Return from subroutine and restore CCR
RTS			-----	-	-	-	-	-	-	-	-	-	-	-	-	-	(SP)+ → PC	Return from subroutine
SBCD	B	Dy,Dx -(Ay),-(Ax)	*U*U*	e	-	-	-	-	-	-	-	-	-	-	-	-	Dx ₁₀ - Dy ₁₀ - X → Dx ₁₀ -(Ax) ₁₀ - -(Ay) ₁₀ - X → -(Ax) ₁₀	Subtract BCD source and eXtend bit from destination, BCD result
Scc	B	d	-----	d	-	d	d	d	d	d	d	d	-	-	-	-	If cc is true then 1's → d else 0's → d	If cc true then d.B = 11111111 else d.B = 00000000
STOP		#n	=====	-	-	-	-	-	-	-	-	-	-	-	-	s	#n → SR; STOP	Move #n to SR, stop processor (Privileged)
SUB ⁴	BWL	s,Dn Dn,d	*****	e	s	s	s	s	s	s	s	s	s	s	s	s ⁴	Dn - s → Dn d - Dn → d	Subtract binary (SUBI or SUBQ used when source is #n. Prevent SUBQ with #n.L)
SUBA ⁴	WL	s,An	-----	s	e	s	s	s	s	s	s	s	s	s	s	s	An - s → An	Subtract address (W sign-extended to .L)
SUBI ⁴	BWL	#n,d	*****	d	-	d	d	d	d	d	d	d	-	-	-	s	d - #n → d	Subtract immediate from destination
SUBQ ⁴	BWL	#n,d	*****	d	d	d	d	d	d	d	d	d	-	-	-	s	d - #n → d	Subtract quick immediate (#n range: 1 to 8)
SUBX	BWL	Dy,Dx -(Ay),-(Ax)	*****	e	-	-	-	-	-	-	-	-	-	-	-	-	Dx - Dy - X → Dx -(Ax) - -(Ay) - X → -(Ax)	Subtract source and eXtend bit from destination
SWAP	W	Dn	---*00	d	-	-	-	-	-	-	-	-	-	-	-	-	bits[31:16] ↔ bits[15:0]	Exchange the 16-bit halves of Dn
TAS	B	d	---*00	d	-	d	d	d	d	d	d	d	-	-	-	-	test d → CCR; 1 → bit7 of d	N and Z set to reflect d, bit7 of d set to 1
TRAP		#n	-----	-	-	-	-	-	-	-	-	-	-	-	-	s	PC → -(SSP); SR → -(SSP); (vector table entry) → PC	Push PC and SR, PC set by vector table #n (#n range: 0 to 15)
TRAPV			-----	-	-	-	-	-	-	-	-	-	-	-	-	-	If V then TRAP #7	If overflow, execute an Overflow TRAP
TST	BWL	d	---*00	d	-	d	d	d	d	d	d	d	-	-	-	-	test d → CCR	N and Z set to reflect destination
UNLK		An	-----	-	d	-	-	-	-	-	-	-	-	-	-	-	An → SP; (SP)+ → An	Remove local workspace from stack
	BWL	s,d	XNZVC	Dn	An	(An)	(An)+	-(An)	(i,An)	(i,An,Rn)	abs.W	abs.L	(i,PC)	(i,PC,Rn)	#n			

Condition Tests (+ OR, ! NOT, ⊕ XOR; * Unsigned, # Alternate cc)					
cc	Condition	Test	cc	Condition	Test
T	true	1	VC	overflow clear	!V
F	false	0	VS	overflow set	V
HI ^u	higher than	!(C + Z)	PL	plus	!N
LS ^u	lower or same	C + Z	MI	minus	N
HS ^u , CC ^u	higher or same	!C	GE	greater or equal	!(N ⊕ V)
LD ^u , CS ^u	lower than	C	LT	less than	(N ⊕ V)
NE	not equal	!Z	GT	greater than	![(N ⊕ V) + Z]
EQ	equal	Z	LE	less or equal	(N ⊕ V) + Z

- An** Address register (16/32-bit, n=0-7)
- Dn** Data register (8/16/32-bit, n=0-7)
- Rn** any data or address register
- s** Source, **d** Destination
- e** Either source or destination
- #n** Immediate data, **i** Displacement
- BCD** Binary Coded Decimal
- ↑** Effective address
- 1** Long only; all others are byte only
- 2** Assembler calculates offset
- 3** Branch sizes: **.B** or **.S** -128 to +127 bytes, **.W** or **.L** -32768 to +32767 bytes
- 4** Assembler automatically uses A, I, Q or M form if possible. Use #n.L to prevent Quick optimization

- SSP** Supervisor Stack Pointer (32-bit)
- USP** User Stack Pointer (32-bit)
- SP** Active Stack Pointer (same as A7)
- PC** Program Counter (24-bit)
- SR** Status Register (16-bit)
- CCR** Condition Code Register (lower 8-bits of SR)
- N** negative, **Z** zero, **V** overflow, **C** carry, **X** extend
- * set according to operation's result, = set directly
- not affected, **0** cleared, **1** set, **U** undefined

Revised by Peter Csaszar, Lawrence Tech University – 2004-2006

Distributed under the GNU general public use license.

Nom : Prénom : Classe :

DOCUMENT RÉPONSE À RENDRE

Exercice 1

Instruction	Mémoire	Registre
Exemple	\$005000 54 AF 00 40 E7 21 48 C0	A0 = \$00005004 A1 = \$0000500C
Exemple	\$005008 C9 10 11 C8 D4 36 FF 88	Aucun changement
MOVE.B #18, -(A1)	\$005000 54 AF 18 B9 E7 21 48 12	A1 = \$00005007
MOVE.W \$500E, (A2)+	\$005010 1F 88 01 80 42 1A 2D 49	A2 = \$00005012
MOVE.W #\$500E, 2(A1)	\$005008 C9 10 50 0E D4 36 1F 88	Aucun changement
MOVE.B 7(A0), 7(A1, D2.W)	\$005008 C9 C0 11 C8 D4 36 1F 88	Aucun changement
MOVE.L -4(A2), -6(A1, D1.L)	\$005008 C9 10 D4 36 1F 88 1F 88	Aucun changement

Exercice 2

Opération	Taille (bits)	Résultat (hexadécimal)	N	Z	V	C
\$59 + \$A7	8	\$00	0	1	0	1
\$FFFF + \$AAAA	16	\$AAA9	1	0	0	1
\$FFFF + \$0100	16	\$00FF	0	0	0	1
\$76543210 + \$12345678	32	\$88888888	1	0	1	0

Exercice 3

```
AlphaCount  jsr   LowerCount
             move.l d0,-(a7)

             jsr   UpperCount
             add.l d0,(a7)

             jsr   DigitCount
             add.l (a7)+,d0

             rts
```

Exercice 4

Question	Réponse
Est-ce que le mode d’adressage Dn spécifie un emplacement mémoire ?	Non
Quels sont les noms des pointeurs de pile superviseur et utilisateur ?	USP et SSP
Si A7 = \$5004 juste avant un RTS, quelle est sa nouvelle valeur juste après le RTS ?	\$5008
Dans quel registre se trouvent les drapeaux (<i>flags</i>) ?	CCR (ou SR)

Exercice 5

Valeurs des registres après exécution du programme. Utilisez la représentation hexadécimale sur 32 bits.		
D1 = \$00000002	D3 = \$00000033	D5 = \$FFFF5200
D2 = \$00000001	D4 = \$00006667	D6 = \$0520370F